



CONNECTION



Operating Instructions

Model No. KX-T30865



Panasonic

nted in the United Kingdom

PQQX5484WA

Please read before use.

Thank you for purchasing the Panasonic Doorphone, KX-T30865

When connecting the doorphone to the Panasonic PBX, a Doorphone / Door Opener Interface Card is required. Please read the Installation Instructions for the Doorphone Card and the Installation Manual for the PBX.

INSTALLATION

- Loosen the screw to separate the doorphone into 2 halves.

Screw
- Install the Lower case to the wall with 2 screws

*2 Types of screw are included. Please choose according to your wall type. See the following.

*

- When a doorphone plate has been fixed to the wall.
- When you wish to install the doorphone directly to the wall.

- Connect the wires from the terminal box to the screws located in the upper case.

to the terminal box
- Secure both halves together and reinstall the screw.

OPERATION



- Push the Call Button and wait for an answer.
- Talk to the doorphone.