



The back of the SWSSI has labels on it next to the pins. Please look close.

#1 & #2 = Normally Closed (Closed when switch is not pushed, Open when pushed)

#3 & #4 = Normally Opened (Open when switch is not pushed, Closed when pushed)

+ = Positive terminal for LED, - = Negative terminal for LED. 12v DC

**(DO NOT MIX UP + & - TERMINALS. THIS WILL DAMAGE LED AND VOID THE WARRANTY)**